



ASSEMBLY INSTRUCTION














MELVILLE DINING TABLE




ROWICO

H O M E




Ax2 	Fx1  M5
Bx2 	Gx8  M8×Ø12
	Hx16  M8×Ø12
	Ix16  M8×Ø20
	Jx8  M8×Ø16
Cx2 	Kx16  M8×30MM
Dx2  60×25×6	Lx8  M8×70MM
Ex4  Ø10×60	Mx4  70×70×3

①




Note:
Do not lift or move assembled table top,
without fully assembled legs.

②




Note:
Improper use, improper assembly and
mishandling may lead to defects/ cracks
appearing.


③



4



5



6

